



GE APPLIANCES
a Haier company

Installation Instructions

Wind Baffle

Before you begin installation, read these instructions completely and carefully. Observe all governing codes and ordinances as they may apply. Leave these instructions with the owner.


▲ IMPORTANT SAFETY NOTICE To avoid personal injury or property damage, this accessory is to be installed only by a licensed and trained industry professional. The manufacturer will not assume liability for unqualified installers or failure to follow these instructions.

▲ WARNING For personal safety, disconnect system power before installing this accessory. During installation, if ground wires, screws, straps, clips, or other means of attaching grounding components are removed, they must be returned to their original positions and fastened securely.

Model: UAWB46A

Parts Included:

- Wind baffle (2 parts)
- 8 stainless self-tapping screws
- 4 screw covers
- This instruction sheet



Step 1:

Remove top screws from grille, slide the wind baffle behind and replace the factory screws.



Step 2:

On some models, the grille screws can be used in the same manner as the top. Use the supplied screws if needed.






Wind Baffle

Step 3:

Drive 3 screws through the front of the wind baffle where the two pieces overlap. This will eliminate any vibration rattle during operation. Cover the ends of the screws with the supplied caps to prevent any injury when reaching down between the baffle and the grille.





GE APPLIANCES
a Haier company

Instructions d'installation

Coupe-vent

Avant de commencer l'installation, veuillez lire ces instructions attentivement et en entier. Observez tous les codes et règlements pertinents en vigueur. Remettez ces instructions au propriétaire.

⚠ IMPORTANT SAFETY NOTICE

Afin de prévenir les blessures et les dommages à la propriété, cet accessoire doit être installé uniquement par un professionnel formé et agréé de notre industrie. Le fabricant exercera son déni de responsabilité si les présentes instructions ne sont pas observées ou si l'installation est réalisée par des individus non qualifiés.


⚠ WARNING

Pour votre sécurité, coupez l'alimentation électrique au système avant d'installer cet accessoire. Si, pendant l'installation, vous retirez des fils de terre, des vis, des brides, des attaches ou tout autre moyen de fixer les composants de mise à la terre, ceux-ci doivent être remis à leur position initiale et fixés solidement.

Modèle: UAWB46A

Pièces incluses :

- Coupe-vent (2 parties)
- 8 vis autotaraudeuses en acier inoxydable
- 4 capuchons de vis
- Ce feuillet d'instructions



Étape 1:

Retirez les vis supérieures de la grille, glissez le coupe-vent derrière celles-ci et remplacez les vis d'origine.



Étape 2:

Sur certains modèles, les vis de la grille peuvent être utilisées de la même façon que dans le haut. Utilisez les vis fournies, si nécessaire.





Étape 3:

Vissez 3 vis dans l'avant du coupe-vent, là où les deux parties se chevauchent. Cela éliminera tout bruit de vibration pendant le fonctionnement. Couvrez les extrémités des vis avec les capuchons fournis pour prévenir toute blessure lorsque vous étendez la main entre le coupe-vent et la grille.

